


Commercial Garment Steamer



Your Steamer provides clean, professional results every time!

- Water container holds 3.5 liters, enough for hours of continuous use.
- No need to empty water from steamer after each use.
- Eliminates ironing by removing wrinkles on the hanger.
- Automatic shut-off safety feature.
- Power indicator light.
- Easy-Roll casters make unit portable.
- Stores upright in a small space.
- Hose hangs on its own hook.
- Steamer handle includes snap-on brush.





Model: ST500

Safety Reminders

- **BEFORE PLUGGING IN** your steamer, be sure the electrical information on the label on the bottom of the base agrees with your power supply. This is a high wattage appliance. To avoid a circuit overload, **DO NOT** operate another high wattage appliance on the same circuit at the same time.
- **READ ALL INSTRUCTIONS** before using your steamer.
- **USE THE STEAMER ONLY** for its intended use.
- **TO PROTECT** against the risk of electric shock, **DO NOT** immerse the appliance in water.
- **ALWAYS** turn the switch to the **OFF** position before plugging in or unplugging the unit.
- **NEVER** yank the cord from the outlet. **ALWAYS** grasp the plug and pull it out to disconnect.
- **DO NOT** allow the cord to touch hot surfaces.
- **DO NOT** leave the steamer unattended while it is operational.
- **ALWAYS** allow the appliance to cool completely for at least thirty minutes before storing.
- **DO NOT** operate the steamer without properly filling the reservoir.
- **ALWAYS** check the water level upon initial operation.
- **ONLY** hang the steamer hose end on the supplied hanger rod.
- **DO NOT** lay the hose on the ground or wind it unnecessarily.
- **MOVE** the appliance by grasping the hose and the hose hanging rod. Do not force the casters. If they stick for some reason, turn the appliance **OFF**, then empty the reservoir and inspect the casters.
- The appliance has a very hot surface. **DO NOT** allow unsupervised children to use it.
- **ALWAYS** disconnect the appliance from the outlet **BEFORE** filling with or removing water. Be careful to **AVOID** spilling excess water into the reservoir when removing or placing the reservoir bottle into the reservoir.
- **DIFFERENT** water sources contain different levels of mineral content. If the steamer begins to cut on and off during normal use, the thermostat is indicating that the unit may have sediment inside which needs to be cleaned out.
- **ALWAYS** allow the unit to cool completely before inspecting or cleaning the interior.
- **ALWAYS** disconnect the appliance when not in use.
- **DO NOT** use the appliance if it has been dropped or damaged. **DO NOT** disassemble the appliance. Incorrect reassembly can cause a risk of electric shock. Send it to an authorized service center for repair.
- **DO NOT** operate another high wattage appliance on the same circuit.
- If an **EXTENSION CORD** is necessary, use a 20 Ampere Cord for 110V/ 120V appliances. Cords rated for less amperage may overheat.
- This appliance **MUST BE** grounded. **DO NOT** alter the plug or attempt to defeat this feature.
- Be careful. Burns can occur from touching **HOT METAL PARTS, HOT WATER, OR STEAM.**



SAVE THESE INSTRUCTIONS!

Steamer Assembly



STEP 1 - ATTACH THE VERTICAL ROD

- Insert the rod assembly into the threaded base adapter on top of the steamer base and hand tighten knob.
- Loosen the telescoping rod assembly knobs and raise upright fully and hand tighten knobs to secure position.
- Slide black handle holder on top of the vertical upright.



STEP 2 - ATTACH THE HOSE

Take the end with the threaded brass screw and place onto the threaded pipe sticking out of the top of the machine. Tighten by hand then slide black plastic screw cover over brass nut to aide in further tightening. Don't over tighten.

STEP 3 - BEFORE FILLING THE WATER BOTTLE

Check to make sure the bottle sits into the reservoir securely and fits properly before proceeding.

Steamer Operation

STEP 1 - PREPARATION FOR USE

1. Set the appliance on the floor and remove the water bottle.
2. Check for sediment or build-up inside the water reservoir.
3. Follow the steps for cleaning and emptying the appliance if water was accidentally left in the water bottle during storage of the unit.
4. Place the steamer hose with the nozzle end up on the hanger rod. Make sure the hose is free of kinks.
5. Make sure that the unit rolls freely.




STEP 2 - FILLING THE WATER BOTTLE

1. Before plugging in the appliance, fill the water bottle.
2. Always make sure the appliance is unplugged before filling the bottle.
3. Fill the water bottle with ordinary, cool tap water.
4. Close the cap tight until it points to the ring as shown on right top.
5. Replace the water bottle straight into the reservoir.



STEP 3 - TURNING ON THE POWER

1. Always check to make sure the ON/OFF switch is OFF.
2. Plug the steamer into an electric outlet.
3. Turn the ON/OFF switch to the ON position.
4. The power indicator light shines when the unit is switched on.



PREPARE GARMENT BEFORE STEAMING

- It will make pressing easier if there are few creases in the apparel.
- To avoid excess creasing, shake each item out before placing them in a drier or hanging them out to dry in the open air.
- For towels, handkerchiefs, and napkins, drape them over a rod or steam press them in place over towel racks!

STEP 4 - USING THE STEAMER

1. Grasp the handle of the steamer hose once the steam is released.
2. Hold the handle with the nozzle facing upward and begin at the bottom of a garment, allowing the escaping steam to rise inside and outside, removing the wrinkles as it rises.
3. After a few seconds, remove the nozzle from the garment. Smooth the garment with your free hand and check to see if more steam is needed.



IMPORTANT NOTE:


For heavier fabrics, you may need to use repeated applications. Avoid heating a single area with steam for a prolonged period. Check the garment periodically to see that the process is succeeding.

With practice, you will gain speed and efficiency. You will also learn which of your clothes require more steam pressing than others.

Steamer Cleaning & Storage

STEP 5 - CLEANING AND STORING THE UNIT

- Turn the ON/OFF switch to the OFF position. The indicator light will go out. As the appliance cools down, disconnect the plug from the outlet.
- Drain the water bottle by removing it and emptying its contents in a sink. Rinse the water bottle lightly, shake out excess moisture, and set it aside to dry.
- Wait for the steamer to cool completely for at least thirty minutes before draining.
- Disconnect the steamer hose from base and set aside.
- Disconnect the rod entirely from the base.
- Lift the base over a sink and empty the water remaining in the reservoir. Wash the interior of the reservoir by flushing it with some fresh water. This will dislodge any sediment that has accumulated. Drain this water from the reservoir.
- Reattach the steamer hose and the hanger rod or store separately.
- Once the appliance has been drained and set aside to dry, you are ready to store it.



IMPORTANT NOTE FOR DAILY USE:

If you wish to leave your steamer ready for use on a daily basis, simply leave the water bottle filled and in place. While you do not have to empty the water bottle each day, you should periodically empty the old water out of the steamer and remove any sediment that has accumulated. Empty it once a month, depending on use and water mineral content in your area.

Operating Notes

WHILE OPERATING STEAMER...

IF THE STEAMER HOSE GURGLES DURING USE...

- This is a normal result of condensation collecting inside the hose. Simply lift the control handle upward until the hose is extended to its full height.
- The gurgling will disappear when the excess moisture inside the hose has had a chance to drain back into the base.

IF THE STEAMER STOPS PRODUCING STEAM, THEN STARTS AGAIN...

- You may wish to examine the inside of the reservoir. The most common reason for this effect is the accumulation of sediment from mineral laden water
- Clean the offending sediment from inside the unit, first following the steps for cooling and cleaning the unit as presented on a previous page.



IF THE “STEAMER INDICATOR READY LIGHT” DOES NOT TURN ON AND THE UNIT DOES NOT PRODUCE STEAM...

- There may be an electrical problem with the appliance. Disconnect the power supply immediately, cool and drain the unit as previously described. DO NOT use the unit until it has been examined by a qualified repair technician,

Trouble Shooting

Below is a chart detailing the most common problems, their causes, and their solutions. Before shipping any appliance to a service center, please check to make sure that the solution is not listed here.

PROBLEM	CAUSE	SOLUTION
Steamer DOES NOT get hot.	Steamer is not plugged into an outlet. Automatic shut-off has engaged. The water bottle is empty and the reservoir has drained	Plug the appliance in. Push the ON/OFF switch to the OFF position. Fill the water bottle and replace inside the reservoir. Once the appliance is refilled, turn the power ON.
No steam.	Water level is too low.	Push the ON/OFF switch to the OFF position. Refill the water bottle and replace inside the reservoir. Once the appliance is filled, turn the power ON.
Water drips from the nozzle.	Condensation has formed inside the steamer hose	Hold the hose upright and allow excess moisture to drain back into the base of the unit.

